

Version 1.1

LigaTrap® Rat IgM Purification Kit, 10 x 0.1 mL Spin Columns

Part # *LT-147KIT*

Kit Contents

Part #	Item	Quantity
LT-147-SC	Microspin Columns- centrifuge columns supplied with caps and plug. Each column contains 0.1 mL LigaTrap® Rat IgM Purification Resin in PBS buffer with 0.05% sodium azide.	10
BU-131-FP	LigaTrap Sample Diluent 2.0	15 mL
BU-132-FP	LigaTrap Equilibration/Wash Buffer 2.0	250 mL
BU-123-FP	LigaTrap Elution Buffer	125 mL
BU-124-FP	LigaTrap Regeneration Buffer	50 mL
BU-125-FP	LigaTrap Neutralization Buffer	15 mL
BU-126-FP	LigaTrap Storage Buffer	50 mL
PL-057	2 mL Collection Tubes	80

Introduction

LigaTrap® Rat IgM Purification Resin is engineered to purify high quality rat IgM antibodies from recombinant and monoclonal sources. Binding capacity for rat IgM is ≥ 10mg/ml resin. The LigaTrap® Rat IgM Purification Kit provides all the necessary reagents for fast, convenient micro-scale purification of rat IgM in just 10 easy steps. Each kit contains 10 microspin columns prefilled with 0.1ml of LigaTrap® Rat IgM Purification Resin, buffers, and collection tubes. Each spin column can be used, regenerated, and used up to 10 times with minimal loss in binding capacity.

Additional Materials Required

- Microcentrifuge set between 1000-3000 x g
- Vortex/Mixer
- Centrifuge tubes or container for sample preparations

Phone: 919-757-6891 · www.LigaTrap.com · Email: techsupport@ligatrap.com

KIT INSTRUCTIONS



Antibody Purification Procedure

Sample Prep

- In a separate tube (not supplied in kit) add 400μl of sample matrix (i.e. supernate or cell culture media) containing rat IgM
- 2. Add 100µl of **LigaTrap Sample Diluent 2.0** to the sample. Mix briefly by vortexing.

Purification

- 3. Equilibrate resin by adding 400µ1 of **LigaTrap Equilibration/Wash Buffer 2.0.** Snap the bottom plug on the Microspin column. Save the plug, as it will be needed to stopper the column. Insert the Microspin column into a supplied 2.0 mL Collection Tube. Centrifuge between 1000-3000 x g for 1 minute. Empty the buffer from Collection Tube. Repeat with an additional 400µ1 equilibration. Insert the bottom plug into the Microspin column.
- 4. Transfer 400μl of prepared sample (Step # 2) to the equilibrated column. Place screw cap on snugly. Vortex briefly for 15 seconds. Continue to mix/shake the sample and resin continuously for 10 min.
- 5. Remove plug and insert the Microspin column into a Collection Tube. Centrifuge between 2000 x g for 1 minute. Discard unbound material or retain for further evaluation.
- 6. Add 400μl of the **LigaTrap Equilibration/Wash Buffer 2.0**. Remove plug and insert Microspin column into a clean Collection Tube. Centrifuge between 1000-3000 x g for 1 minute. Discard wash. Repeat with two additional washes for a total of three washes. (3x400μl)
- 7. Insert the washed Microspin column into a <u>new, labeled</u> Collection Tube. Add 400µl of **LigaTrap Elution Buffer** to the column. Vortex briefly for 15 seconds. Centrifuge between 1000-3000 x g for 1 minute. Place the Microspin column into a new, labeled Collection Tube. Repeat with second 400µl elution. *Note: The eluates contain the purified antibodies. Do not discard!
- 8. Pool eluates from Step 7 and add 100µl of **LigaTrap Neutralization Buffer** to the antibody. Attach the cap. Vortex briefly. The antibody will be near neutral pH. The antibody is ready for downstream applications. *Note: There are no preservatives in the antibody. Use the antibody within one week or aliquot and store at -20° C or colder. Avoid multiple freeze thaws.*
- 9. If the column will not be reused, it can be discarded. If column is to be reused, regenerate the column by adding 400μl of **LigaTrap Regeneration Buffer**. Vortex briefly for 15 seconds. Insert the Microspin column into a 2.0 mL Collection Tube and centrifuge between 1000-3000 x g for 1 minute.
- 10. To store resin add 400μl of **LigaTrap Storage Buffer.** Insert the Microspin column into a 2.0 mL Collection Tube. Centrifuge between 1000-3000 x g for 1 minute. Discard wash. Repeat with an additional two washes for a total of three washes. (3x400μl) Insert the bottom plug into the Microspin column, add 400μl of fresh **LigaTrap Storage Buffer** and store at 2-8° **C**.

Phone: 919-757-6891 · www.LigaTrap.com · Email: techsupport@ligatrap.com